

CASTER PAD CONSTRUCTION FEATURES

Load Capacity 225-500 lbs.

- A faster, easier, more efficient and economical way to attach Top Plate Casters to trash containers and equipment (No welding or thru hole bolting required)
- Each Caster attaches in seconds
- Eliminates welding or bolting new replacements to bottom of container.
- Allows easy service replacement of casters in the field.

CASTER PAD ORDERING NUMBERS

Order Number	Caster
CP-02	02 Category Top Plate
CP-4-12	4-12 Category Top Plate
CP-4-16	4-16 Category Top Plate
CP-5-62	5-62 Category Top Plate

To Install Caster to Pad, Follow These 3 Easy Steps:

1. Snap caster into Fast-Lock Caster Pad



2. Insert Non-Slipping Pin in holes and turn into locked position



3. Attach Lock Washer and Nut to Pin and tighten for reinforcement.